USER GUIDE

www.fiberopticlink.com

UG-M090 2024-11-25

2 Plate Wall Mount Fiber Patch Panel

Wall Mount Housing for Splicing and Patching up to 48 Fibers

The RLH 2 Plate Wall Mount Fiber patch panel is a flexible and easy to use housing for fiber optic patching and splicing.

This wall mount design patch panel holds 2 LGX style adapter plates, and features a full width, wrap-around door which provides total interior access and is secured with flip latches. It includes 4 self sealing 1 ½" cable entry grommets on the top and bottom for safe entry and exit of fiber optic cable, a built-in strength member clamp, and anchor points for organizing cable routing.

It comes complete with stacking fiber splice holders, splice protection sleeves, distribution chart, hook-and-loop straps for securing cable, cable ties and stainless steel wall mounting hardware.

Adapter plates may be ordered separately or preinstalled and are available with ST, SC, FC, LC, MTRJ, UPC and APC style adapters. When ordered using our configuration matrix, the Adapter Plates are preinstalled, and the Splice on Fiber Pigtails are bundled with the patch panel for convenience.

Key Features

- Holds 2 LGX® adapter plates, blank adapter plates included
- Full access, wrap around door with flip latches
- Small footprint, housing fully encloses distribution fiber
- Includes stacking splice holders and splice protection sleeves
- Multiple built-in anchor points to secure fiber cable routing
- Self sealing grommets (up to 1 ½") on the top and bottom
- Strain relief clamp for securing entry cable
- Includes hook and loop straps for cable management
- Holds ST, SC, FC, LC, MTRJ, UPC, APC style adapters
- Durable steel construction
- Wall mounting hardware included



2 Plate Wall Mount Fiber Patch Panel



Included Accessories

USER GUIDE

www.fiberopticlink.com

Installation

Wall Mounting

Choose a suitable location, with room for the door to open fully for easy access to the interior. Pre-position the patch panel to plan out cable routings and check for any potential problems with the location. The patch panel may be mounted in any orientation making it a flexible solution in the field.


Once the position is determined, mark out the mounting points and use the included hardware to mount the patch panel when mounting to wood surfaces. For all other mounting applications, use the appropriate mounting hardware as required.

Adapter Plates

The 2 Plate Wall Mount Fiber Patch Panel accommodates LGX adapter plates. The LGX style adapter plates are easily installed and removed by pushing in or pulling out the two finger plunger latches on each side of the plate. when the plunger latches are In the OUT position, the fiber adapter plate can be inserted or removed. Pushing the latch into the IN position locks the adapter plate into position and prepares the plate for use.

Splice Holders

The fiber splice holders adhere to the main compartment in the fiber patch panel. They're stackable and held in place by dual sided adhesive foam tape. They are only needed when splicing fiber optic cable as they're designed to hold the included fiber splice sleeves in place.



USER GUIDE

www.fiberopticlink.com

Ordering Information


Use the following part number when ordering the patch panel without fiber adapter plates or pigtails.

Description	Capacity	Dimensions	Part Number
2 Plate Wall Mount Fiber Patch Panel	2 Fiber Adapter Plates	12.2" (W) x 2.5" (D) x 5.9" (H)	WMP2-A-1

■ Fiber adapter plates and/or pigtails can be ordered separately; plates can be preinstalled, while pigtails will be bundled

Ordering with Fiber Adapter Plates and Pigtails

Use the ordering code below to order the patch panel with fiber adapter plates preinstalled and/or pigtails included. Refer to the Fiber Adapter Plate Chart and the Fiber Pigtail Chart on the following pages.



*Please refer to the Fiber Adapter Plate Chart and the Fiber Pigtail Chart on the following pages.



USER GUIDE

www.fiberopticlink.com

Ordering Information (cont'd)

Adapter Plate Chart

Use the Adapter Code to specify the desired plate style to be preinstalled.

Adapter Plate Style					Supported	Grey Plate	Adapter			
Adapter	Mode	Туре	Fibers	Positions	Color	Fiber Types	Part Number	Code		
Blank	_	_	_	_	_	_	AP-BLANK-G	00		
	SM	Simplex	6	6	Yellow Caps	OS1/OS2	AP-ST6-LSSM-G	01		
ST	- JIVI	Simplex	12	12	Yellow Caps	OS1/OS2	AP-ST12-LSSM-G	03		
31	ММ	Simplex	6	6	Black Caps	OM1~OM4	AP-ST6-LSMM-G	06		
	141141	Olitipiex	12	12	Black Caps	OM1~OM4	AP-ST12-LSMM-G	08		
FC	SM	Simplex	6	6	Yellow Caps	OS1/OS2	AP-FC6-LSSM-G	20		
	MM	Simplex	6	6	Black Caps	OM1/OM2	AP-FC6-LSMM-G	23		
FC/APC	SM	Simplex	6	6	Green Caps	OS1/OS2	AP-FA6-LSSM-G	26		
	SM	Simplex	6	6	blue	OS1/OS2	AP-SC6-LSSM-G	30		
SC	SIVI	Duplex	12	6	blue	OS1/OS2	AP-SC6-LDSM-G	32		
33	ММ	Simplex	6	6	beige	OM1/OM2	AP-SC6-LSMM-G	33		
	IVIIVI	Duplex	12	6	beige	OM1/OM2	AP-SC6-LDMM-G	35		
CC/A DC	CM	Simplex	6	6	■ green	OS1/OS2	AP-SA6-LSSM-G	36		
SC/APC	SM	Duplex	12	6	■ green	OS1/OS2	AP-SA6-LDSM-G	38		
00.400	5454	Simplex	6	6	aqua	OM3/OM4	AP-SC6-LSMX-G	39		
SC 10G	MM	Duplex	12	6	aqua	OM3/OM4	AP-SC6-LDMX-G	41		
		Dunlass	6	3	blue	OS1/OS2	AP-LC3-LDSM-G	51		
	SM	Duplex	12	6	blue	OS1/OS2	AP-LC6-LDSM-G	52		
LC		Quad	24	6	blue	OS1/OS2	AP-LC6-LQSM-G	54		
LC		Dunlay	6	3	beige	OM1/OM2	AP-LC3-LDMM-G	56		
	MM	Duplex	12	6	beige	OM1/OM2	AP-LC6-LDMM-G	57		
		Quad	24	6	beige	OM1/OM2	AP-LC6-LQMM-G	59		
		Duploy	6	3	■ green	OS1/OS2	AP-LA3-LDSM-G	61		
LC/APC S	SM	Duplex	12	6	green	OS1/OS2	AP-LA6-LDSM-G	62		
		Quad	24	6	■ green	OS1/OS2	AP-LA6-LQSM-G	64		
LC 10 GIG	ММ			Duploy	6	3	aqua	OM3/OM4	AP-LC3-LDMX-G	66
		Duplex	12	6	aqua	OM3/OM4	AP-LC6-LDMX-G	67		
		Quad	24	6	aqua	OM3/OM4	AP-LC6-LQMX-G	69		
CAT6 RJ-45		Coupler	-	4	-	-	AP-RJCAT6-CP4-G	90		
CAID RJ-45		Punchdown	-	4	-	-	AP-RJCAT6-PD4-G	91		

USER GUIDE

www.fiberopticlink.com

Ordering Information (cont'd)

Fiber Pigtail Chart

Use the Pigtail Code to specify the desired 900µm Spiral Wrap Splice-on Fiber Pigtail to be included.

N/A	900µm Spiral Wrap Splice-on Pigtail			e-on Pigtail	David N	Pigtail	
N/A	Adapter	Mode	Fibers	Fiber Type	Part Number		
SM	•				NONE	00	
SM	1074						
ST		SM					
ST			12				
ST			_				
MM			6				
12	ST						
SM		IVIIVI		OM1	RLH-12MMST-03M	12	
SM			40	OM2	RLH-12M5ST-03M	13	
SM			12	OM3	RLH-12MXST-03M	14	
FC MM 12				OM4	RLH-12MCST-03M	15	
FC MM 6 OM1 RLH-06MMFC-03M 23 OM2 RLH-06MMFC-03M 24 OM3 RLH-06MMFC-03M 25 OM4 RLH-06MMFC-03M 25 OM4 RLH-06MMFC-03M 26 OM3 RLH-12MMFC-03M 28 OM2 RLH-12MMFC-03M 29 OM3 RLH-12MMFC-03M 30 OM4 RLH-12MMFC-03M 31 OM4 RLH-12MMFC-03M 40 OM4 RLH-06MMSC-03M 41 OM1 RLH-06MMSC-03M 41 OM2 RLH-06MMSC-03M 45 OM2 RLH-06MMSC-03M 45 OM2 RLH-06MMSC-03M 45 OM2 RLH-06MMSC-03M 45 OM4 RLH-12MMSC-03M 48 OM2 RLH-12MMSC-03M 48 OM2 RLH-12MMSC-03M 48 OM4 RLH-12MMSC-03M 51 OM4 RLH-12MMSC-03M 51 OM4 RLH-12MMSC-03M 51 OM4 RLH-12MMSC-03M 51 OM4 RLH-12MMSC-03M 60 OM4 RLH-12MMSC-03M 60 OM4 RLH-12MMSC-03M 60 OM4 RLH-12MMSC-03M 61 OM4 RLH-12MMSC-03M 62 OM4 RLH-12MMSC-03M 63 OM2 RLH-06MMSC-03M 65 OM4 RLH-12MMSC-03M 65 OM4 RLH-12MMSC-03M 66 OM3 RLH-06MMSC-03M 66 OM3 RLH-06MMSC-03M 66 OM3 RLH-06MMSC-03M 66 OM4 RLH-12MMSC-03M 66 OM4 RLH-12MMSC-03M 67 OM4 RLH-12MMSC		014	6	OS1/OS2	RLH-06SMFC-03M	20	
FC MM 6 OM2 RLH-06M5FC-03M 24 OM3 RLH-06MXFC-03M 25 OM4 RLH-12MMFC-03M 26 OM4 RLH-12MMFC-03M 28 OM2 RLH-12M5FC-03M 30 OM4 RLH-12M5FC-03M 30 OM4 RLH-12M5FC-03M 30 OM4 RLH-12M5FC-03M 31 OM5 RLH-06SM5C-03M 40 OM5 RLH-06SM5C-03M 40 OM5 RLH-06MM5C-03M 41 OM5 RLH-06M5SC-03M 45 OM4 RLH-06M5SC-03M 45 OM4 RLH-06M5SC-03M 45 OM4 RLH-06M5SC-03M 45 OM5 RLH-06SMSC-03M 45 OM6 RLH-12M5SC-03M 45 OM6 RLH-12M5SC-03M 50 OM4 RLH-12M5SC-03M 51 OS1/OS2 RLH-06SMSA-03M 53 OS1/OS2 RLH-06SMSA-03M 53 OS1/OS2 RLH-06SMSA-03M 53 OS1/OS2 RLH-06SMSA-03M 60 OS1/OS2 RLH-12SMSA-03M 60 OS1/OS2 RLH-12SMSA-03M 61 OM5 RLH-06M5LC-03M 60 OM6 RLH-12M5C-03M 60 OM6 RLH-06M5LC-03M 61 OM6 RLH-06M5LC-03M 65 OM6 RLH-06M5LC-03M 66 OM6 RLH-06M5LC-03M 66 OM6 RLH-06M5LC-03M 66 OM6 RLH-12M5LC-03M 66 OM6 RLH-12M5LC-03M 66 OM6 RLH-12M5LC-03M 66 OM6 RLH-12M5LC-03M 67 OM6 RLH-12M5L		SIVI	12	OS1/OS2	RLH-12SMFC-03M	21	
FC MM MM Composition Com				OM1	RLH-06MMFC-03M	23	
FC MM OM4			6				
MM	FC		J				
Part	FU	ММ					
FC/APC SM							
FC/APC SM			12				
FC/APC SM 6 OS1/OS2 RLH-06SMFA-03M 34 SM 6 OS1/OS2 RLH-12SMFA-03M 40 SM 6 OS1/OS2 RLH-06SMSC-03M 40 12 OS1/OS2 RLH-12SMSC-03M 41 OM1 RLH-06MMSC-03M 43 OM2 RLH-06MSSC-03M 44 OM3 RLH-06MSSC-03M 45 OM4 RLH-12MMSC-03M 48 OM2 RLH-12MMSC-03M 49 OM3 RLH-12MSSC-03M 49 OM4 RLH-12MSSC-03M 50 OM4 RLH-12MSSC-03M 51 SC/APC SM 6 OS1/OS2 RLH-12SMSA-03M 53 SC/APC SM 6 OS1/OS2 RLH-06SMSA-03M 54 SM 12 OS1/OS2 RLH-12SMSA-03M 54 OM1 RLH-12MMSC-03M 60 SM 12 OS1/OS2 RLH-12SMSC-03M 60 SM 12 OS1/OS2 RLH-12SMSC-03M 61 COM1 RLH-06MMLC-03M 63 OM2 RLH-12MMCC-03M 63 OM4 RLH-12MMCC-03M 63 OM2 RLH-06MSLC-03M 64 OM3 RLH-06MSLC-03M 65 OM4 RLH-12MMLC-03M 65 OM4 RLH-12MMLC-03M 68 OM2 RLH-106MSLC-03M 69 OM4 RLH-12MMLC-03M 69 OM4 RLH-12MMLC-03M 70 OM4 RLH-12MMLC-03M 70 OM4 RLH-12MSLC-03M 71 OM1 RLH-12MMLC-03M 71 OM2 RLH-12MSLC-03M 72 OM3 RLH-12MSLC-03M 73 OM4 RLH-12MSLC-03M 74 OM3 RLH-12MSLC-03M (2) 75 OM4 RLH-12MSLC-03M (2) 75							
SM							
SM 6 OS1/OS2 RLH-12SMFA-03M 40 12 OS1/OS2 RLH-06SMSC-03M 41 OM1 RLH-06MMSC-03M 43 OM2 RLH-06MSSC-03M 44 OM3 RLH-06MSSC-03M 45 OM4 RLH-06MSSC-03M 45 OM4 RLH-12MMSC-03M 48 OM2 RLH-12MSC-03M 49 OM2 RLH-12MSC-03M 49 OM3 RLH-12MSC-03M 50 OM4 RLH-12MSC-03M 50 OM4 RLH-12MSC-03M 51 SC/APC SM 6 OS1/OS2 RLH-06SMSA-03M 53 12 OS1/OS2 RLH-12SMSA-03M 54 OS1/OS2 RLH-12SMSC-03M 60 SM 12 OS1/OS2 RLH-12SMSC-03M 61 OM1 RLH-06MMLC-03M 61 OM2 RLH-106MMLC-03M 63 OM3 RLH-12MSC-03M 63 OM4 RLH-06MMLC-03M 63 OM2 RLH-06MSLC-03M 64 OM3 RLH-06MMLC-03M 65 OM4 RLH-06MMLC-03M 66 OM3 RLH-12MSLC-03M 66 OM4 RLH-12MSLC-03M 69 OM4 RLH-12MSLC-03M 69 OM4 RLH-12MSLC-03M 70 OM4 RLH-12MSLC-03M 71 OM4 RLH-12MSLC-03M (2) 73 OM4 RLH-12MSLC-03M (2) 73 OM4 RLH-12MSLC-03M (2) 75	FC/APC	SM					
SM 12 OS1/OS2 RLH-12SMSC-03M 41 OM1 RLH-06MMSC-03M 43 OM2 RLH-06MSC-03M 44 OM3 RLH-06MSC-03M 45 OM4 RLH-06MSC-03M 45 OM4 RLH-12MMSC-03M 45 OM2 RLH-12MMSC-03M 46 OM3 RLH-12MSSC-03M 49 OM2 RLH-12MSSC-03M 50 OM4 RLH-12MSSC-03M 50 OM4 RLH-12MCSC-03M 51 OS1/OS2 RLH-06SMSA-03M 53 OS1/OS2 RLH-06SMSA-03M 53 OS1/OS2 RLH-06SMSA-03M 54 OS1/OS2 RLH-12SMSA-03M 60 OS1/OS2 RLH-12SMLC-03M 60 OS1/OS2 RLH-12SMLC-03M 61 OM2 RLH-12SMLC-03M 61 OM2 RLH-06MMLC-03M 63 OM2 RLH-06MMLC-03M 63 OM2 RLH-06MMLC-03M 65 OM4 RLH-06MSLC-03M 66 OM3 RLH-06MSLC-03M 65 OM4 RLH-06MSLC-03M 66 OM2 RLH-12MSLC-03M 66 OM2 RLH-12MSLC-03M 67 OM4 RLH-12MSLC-03M 70 OM4 RLH-12MSLC-03M 70 OM4 RLH-12MSLC-03M 71 OM4 RLH-12MSLC-03M 71 OM4 RLH-12MSLC-03M 71 OM3 RLH-12MSLC-03M 71 OM3 RLH-12MSLC-03M 71 OM3 RLH-12MSLC-03M (2) 75 OM4 RLH-12MSLC-03M (2) 75 OM5 RLH-12MSLC-	1 0,7 11 0	<u> </u>					
SC MM RLH-12SMSC-03M 43 OM1 RLH-06MMSC-03M 44 OM2 RLH-06MSC-03M 44 OM3 RLH-06MSC-03M 45 OM4 RLH-06MSC-03M 46 OM4 RLH-12MSC-03M 48 OM2 RLH-12MSC-03M 46 OM4 RLH-12MSC-03M 49 OM2 RLH-12MSC-03M 50 OM4 RLH-12MSC-03M 51 OM4 RLH-12MSC-03M 51 SC/APC SM 6 OS1/OS2 RLH-06SMSA-03M 53 12 OS1/OS2 RLH-12SMSA-03M 54 OS1/OS2 RLH-12SMSC-03M 60 SM 12 OS1/OS2 RLH-12SMSC-03M 61 24 OS1/OS2 RLH-12SMLC-03M 61 OM1 RLH-06MMLC-03M 63 OM2 RLH-06MSLC-03M 63 OM4 RLH-06MSLC-03M 65 OM4 RLH-06MSLC-03M 66 OM3 RLH-06MSLC-03M 65 OM4 RLH-12MSLC-03M 69 OM4 RLH-12MSLC-03M 69 OM7 RLH-12MSLC-03M 70 OM8 RLH-12MSLC-03M 71 OM1 RLH-12MSLC-03M 71 OM1 RLH-12MSLC-03M (2) 73 OM2 RLH-12MSLC-03M (2) 73 OM4 RLH-12MSLC-03M (2) 75		SM					
SC			12				
SC							
SC			6				
NMM	sc						
12		MM					
SC/APC SM 6							
OM4 RLH-12MCSC-03M 51			12				
SC/APC SM 6							
SC/APC SM 12			6				
SM 12	SC/APC	SM					
LC MM 12							
LC MMM 6 OS1/OS2 RLH-12SMLC-03M (2) 62 OM1 RLH-06MMLC-03M 63 OM2 RLH-06M5LC-03M 64 OM3 RLH-06M5LC-03M 65 OM4 RLH-06M6LC-03M 66 OM4 RLH-12MMLC-03M 68 OM2 RLH-12MMLC-03M 69 OM3 RLH-12M5LC-03M 70 OM4 RLH-12M6LC-03M 71 OM4 RLH-12M6LC-03M 71 OM1 OM1 RLH-12M6LC-03M (2) 73 OM2 RLH-12M5LC-03M (2) 75 OM4 RLH-12M5LC-03M (2) 75 OM4 RLH-12M5LC-03M (2) 75 OM4 RLH-12M6LC-03M (2) 75 OM4 RLH-12M6LC-03M (2) 75 OM4 RLH-12M6LC-03M (2) 75 OM4 RLH-12M6LC-03M (2) 76		CW					
LC MMM 6 OM1 OM2 RLH-06MMLC-03M 64 OM3 RLH-06M5LC-03M 65 OM4 RLH-06MCLC-03M 66 OM4 RLH-106MCLC-03M 66 OM2 RLH-12MMLC-03M 68 OM2 RLH-12M5LC-03M OM3 RLH-12MSLC-03M OM4 RLH-12MCLC-03M OM4 RLH-12MCLC-03M OM4 RLH-12MCLC-03M OM1 RLH-12MMLC-03M OM1 RLH-12MMLC-03M OM2 RLH-12MSLC-03M OM3 RLH-12MSLC-03M OM4 RLH-12MSLC-03M OM4 RLH-12MSLC-03M OM5 OM4 RLH-12MSLC-03M OM6 OM7 OM7 OM7 OM7 RLH-12MSLC-03M OM7 OM7 OM8 RLH-12MSLC-03M OM7 OM8 RLH-12MSLC-03M OM7 OM8 RLH-12MSLC-03M OM7 OM8 RLH-12MSLC-03M OM7 OM7 OM8 OM8 RLH-12MSLC-03M OM7 OM7 OM8 OM8 RLH-12MSLC-03M OM7 OM7 OM8 OM8 OM8 RLH-12MSLC-03M OM7 OM8 OM8 OM8 OM8 OM8 OM8 OM		SIVI	JIVI				
LC MMM 64 OM2 RLH-06M5LC-03M 64 OM3 RLH-06MXLC-03M 65 OM4 RLH-06MCLC-03M 66 OM1 RLH-12MMLC-03M 68 OM2 RLH-12MSLC-03M 69 OM3 RLH-12MXLC-03M 70 OM4 RLH-12MXLC-03M 71 OM1 RLH-12MMLC-03M (2) 73 OM2 RLH-12MSLC-03M (2) 74 OM3 RLH-12MXLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76			47				
LC			_				
MM OM4 RLH-06MCLC-03M 66 OM1 RLH-12MMLC-03M 68 OM2 RLH-12M5LC-03M 69 OM3 RLH-12MXLC-03M 70 OM4 RLH-12MCLC-03M 71 OM1 RLH-12MMLC-03M (2) 73 OM2 RLH-12M5LC-03M (2) 74 OM3 RLH-12M5LC-03M (2) 75 OM4 RLH-12M5LC-03M (2) 75 OM4 RLH-12M5LC-03M (2) 76 OM4 RLH-12M5LC-03M (2) 76 OM5 RLH-12M5LC-03M (2) 76	LC		6				
MMM OM1 RLH-12MMLC-03M 68 OM2 RLH-12M5LC-03M 69 OM3 RLH-12MXLC-03M 70 OM4 RLH-12MCLC-03M 71 OM1 RLH-12MMLC-03M (2) 73 OM2 RLH-12M5LC-03M (2) 74 OM3 RLH-12MXLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76 6 OS1/OS2 RLH-06SMLA-03M 78							
12		MM					
OM3 RLH-12MXLC-03M 70 OM4 RLH-12MCLC-03M 71 OM1 RLH-12MMLC-03M (2) 73 OM2 RLH-12M5LC-03M (2) 74 OM3 RLH-12MXLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76 OS1/OS2 RLH-06SMLA-03M 78			40				
OM4 RLH-12MCLC-03M 71 OM1 RLH-12MMLC-03M (2) 73 OM2 RLH-12M5LC-03M (2) 74 OM3 RLH-12M5LC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76 OS1/OS2 RLH-06SMLA-03M 78			12				
24 OM2 RLH-12M5LC-03M (2) 74 OM3 RLH-12MXLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76 6 OS1/OS2 RLH-06SMLA-03M 78						71	
24 OM2 RLH-12M5LC-03M (2) 74 OM3 RLH-12MXLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76 6 OS1/OS2 RLH-06SMLA-03M 78					RLH-12MMLC-03M (2)		
OM3 RLH-12MXLC-03M (2) 75 OM4 RLH-12MCLC-03M (2) 76 6 OS1/OS2 RLH-06SMLA-03M 78			24		RLH-12M5LC-03M (2)	74	
6 OS1/OS2 RLH-06SMLA-03M 78					RLH-12MXLC-03M (2)	75	
					RLH-12MCLC-03M (2)	76	
	LC/APC	SM		OS1/OS2			
24 OS1/OS2 RLH-12SMLA-03M (2) 80				24	OS1/OS2	RLH-12SMLA-03M (2)	80



USER GUIDE

www.fiberopticlink.com

Key Specifications

Adapter Plates: (ordered separately)	Holds 2 LGX® plates up to 24 Fibers each plate *Includes 2 blank adapter plates when not ordered with accompanying adapter plates
Mounting Style:	Wall or panel mount
Environmental:	Indoor or inside weatherproof enclosure
Construction:	Steel with hinged door, painted gray
Included Accessory Kit:	Qty. 4 – 4" x ½" hook-and-loop straps for securing fiber cable Qty. 2 – 24 fiber, stacking fiber splice holders with adhesive strip Qty. 50 – Fiber splice protection sleeves Qty. 10 – 4" cable ties for securing entry cable Qty. 4 – #10 x ¾" stainless steel mounting screws and washers Qty. 1 – Self adhesive fiber distribution chart
Dimensions:	12.2 " (W) x 2.5" (D) x 5.9" (H), (310mm x 64mm x 150mm) *Not including latches or grommets

Contact

By Mail:	936 N. Mair	Att: Sales RLH Industries, Inc. 936 N. Main St. Orange, CA 92867	
By Phone: Sales / Service Mon - Fri, 6am - 6pm, PST	Local Toll Free	714-532-1672 800-877-1672 866-DO-FIBER	
By Email:	info@fiberopticlink.com		
By FAX:	714-532-1885		

Tech Support

By Email:	support@fiberopticlink.com
By Phone:	Toll Free 855-754-2497
•	855-RLH-24X7